



VR 6500



Technicien de maintenance /Maintenance Technician

Jérôme Helary

Phone : 06.42.86.50.46

Sav@paclite-equip.com





Vibration cable .

When you remove the vibration cable check that the cable don't touch the metal .

Ok





If you have not vibration adjust the two bolts.

