## **VR800 ROLLER PROBLEM**


<u>Problem:</u> All hydraulic oil had leaked out **under the pump**. Please advise what to do? <u>Attached Image:</u>



## **Possible Causes:**


- The image attached while reporting the problem is that of Exciter block(Vibration Casing). The chance of oil leaking from this part is rare. This part contains
  - 1. Eccentric mass
  - 2. Pulley and other Attachments
  - 3. Gear

Please see below image:



Picture-1

- Unscrew this ROL800DK-HHOS.B-M16X1.5 and drain all the oil from gear casing.
- Verify the threads of this bolt; whether it is broken or worn out. Check the washer for possible damages (Refer Picture-2). If answer is yes; replace the bolt or washer.



Picture-2

• Unscrew the gear casing cover and check the O-ring for possible damages. If it is damaged, replace it with new one.

## **Conclusion:**

Above listed bullet points are the possible causes of oil leakage from the exciter block.

Check hydraulic oil hoses for leakages.

Ensure All Connectors are tight.