




SYNCHROMASTER 38/42/52/58

220-240V/50-60Hz - 115-130V/50-60Hz

(THERMAL VERSION)



ELECTRONIC POKER (230V-50Hz/115V-60Hz)		
MODEL	CODE	
	230V/200Hz	115V/200Hz
SYNCHROMASTER 38	10.157	10.386
SYNCHROMASTER 42	10.158	10.387
SYNCHROMASTER 52	10.159	10.388
SYNCHROMASTER 58	10.160	10.389
SYNCHROMASTER 52 RC	10.175	10.434
SYNCHROMASTER 58 RC	10.176	10.435

POKER HEAD (230V / 200Hz)		
MODEL	230V/200Hz	115V/200Hz
SYNCHROMASTER 38	22.550	22.576
SYNCHROMASTER 42	22.551	22.577
SYNCHROMASTER 52	22.552	22.578
SYNCHROMASTER 58	22.553	22.579
SYNCHROMASTER 52 RC	22.572	22.582
SYNCHROMASTER 58 RC	22.573	22.583

SET CONVERTER SUB-ASSY.

SYNCHROMASTER 38 (230V) - 22.487
 SYNCHROMASTER 42/52/58 (230V) - 22.488
 SYNCHROMASTER 38 (115V) - 22.501
 SYNCHROMASTER 42/52/58 (115V) - 22.502